

BRZDNÉ ODPORY



Označení	Přiřazení k měniči	U [V]	P [W]	R [Ω]	L	L ₁
BOE-90-110	002N - 005N	230	250	193,6	310	192
BOE-90-130	007N - 011N	230	500	96,8	310	192
BOE-90-160	015N - 022N	230	1000	48,4	400	282
BOE-90-250	004H - 015H	400	750	192,5	400	282
BOE-90-490	022H - 040H	500	2500	100	580	462
BOE-90-280	055H - 075H	400	2000	72,2	580	462
BOE-90-290	110H	400	2500	57,8	580	462
BOE-90-190	BRD01	230	2500	19,36	580	462

